


STEEL OVER THE TIRE TRACK

Z SERIES (BAR STYLE)

F SERIES (SOLID PAD)






Table of Contents

F SERIES STEEL TRACK (SOLID PAD)

1. F SERIES PARTS LIST	Page 1
2. STEEL TRACK ACCESSORIES	Page 2
3. CURRENT F SERIES BREAKDWN	Page 3
4. PARTS BREAKDOWN 4-5-01 TO 1-14-0	2 Page 4
5. PARTS BREAKDOWN 9-1-00 TO 4-5-01	Page 5
6. PARTS BREAKDOWN 5-1-96 TO 9-1-00	Page 6

Z SERIES STEEL TRACK (BAR STYLE)

1	Z SERIES PARTS LIST	Page 7
2	CURRENT Z SERIES BREAKDWN	Page 8

STEEL TRACK INFORMATION

1. TRACK TO TIRE FIT	Page 9
2. TRACTION BEAD REBUILD INSTRUCTIONS	Page 10
3. DURA PIN AND LINKAGE WEAR LIMITS	Page 11
4. OBSOLETE STEEL TRACK PARTS	Page 12

IMPORTANT

THE OLD QUICK PINS (KNURLING UNDER THE HEAD) THAT WERE USED FROM 5-1-96 TO 9-1-00 ARE NO LONGER AVAILABLE. THEY HAVE BEEN REPLACED WITH A HARDENED DOWEL PIN THAT HAS TO BE TACK WELDED TO THE OUTER AND INNER SIDE PLATES.

PARTS ARE NOT AVAILABLE FOR ANY STEEL TRACKS BUILT PRIOR TO 1996.

REPLACING BOLTS AND NUTS ON YOUR TRACK

WHEN REPLACING THE NUTS AND BOLTS ON YOUR STEEL TRACK THE NUTS HAVE TO BE TORQUED AT 80 FT/LBS.